

OWNER'S MANUAL KLEPCYS DOUBLE CHRONOGRAPH DICE

Congratulations on the purchase of your CYRUS timepiece and thank you for the trust!

We are very proud to welcome you to the selected group of happy owners of this exceptional watch.

The KLEPCYS DICE features a unique and innovative mono-pusher double chronograph capable of measuring two short intervals of time independently or in synchrony. This creation is produced in our Manufacture Chronode in Le Locle, Switzerland, and is equipped with the new in-house self-winding CYR718 manufacture movement.


By choosing CYRUS KLEPCYS DICE, you have chosen innovation, exclusivity and a strong identity.

We invite you to consult the instructions for use and wish you an excellent journey in the universe of CYRUS timepieces.

CYRUS, The Conquest of Innovation

CONTROLS AND INDICATIONS

- A. Hours and minutes hands
- B. Small seconds
- C. Dual 30-minute counter
- D. Central chronograph seconds hand with reset at 12h, chrono n°1
- E. Central chronograph seconds hand with reset at 6h, chrono n°2
- F. Small minutes counter hand, chrono n°1
- G. Small minutes counter hand, chrono n°2
- H. Winding and time-setting crown, push-button for start/stop/reset chrono n°1
- I. Push-button for start/stop/reset chrono n°2



OPERATING INSTRUCTIONS

Crown at 3 o'clock

WINDING THE WATCH

Position I

Turn the crown clockwise to wind the watch. The small seconds display (B) will activate. When the movement is fully wound (about 50 turns of the crown), a power reserve of 60 hours is granted. The automatic movement allows the watch to wind up by simply using the energy produced by the wearer's own movement. If the watch stops, you need to wind it manually by turning the crown.

SETTING THE TIME

Position I'

Pull out the crown in position I' (one click). Hours and minutes hands (A) rotate both clockwise and anticlockwise to set the desired time.

USING THE CHRONOGRAPH

Klepcys DICE allows to measure two elapsed times independently or in synchrony. This chronograph counts one or two additional periods of time in seconds (D-E) and minutes (F-G) showing the elapsed time/times on the 30-minute counter (C). The two chronographs are distinguished by two colors. The chronograph activation crown corresponds to the same color of the hands and minutes scale on the flange.

Crown at 3 o'clock – chrono n°1

Pressing the push-button at 3 o'clock (H) starts, stops and resets the chronograph at 12 o'clock.

Crown at 9 o'clock – chrono n°2

Pressing the push-button at 9 o'clock (I) starts, stops and resets the chronograph at 6 o'clock.

If you want to activate only one chronograph, it's your choice which one to use. To activate them in synchrony, press the push-buttons on the two crowns at the same time.

Finally, we recommend you have your watch checked and serviced through an official representative of the CYRUS brand every 3 years and you will enjoy your watch for lifetime.


Notes: By subscribing our CYRUS Circle on cyrus-watches.ch and registering your watch before the expiry of the regular 2-year warranty, you will be granted an additional 2-year warranty extension that covers any manufacturing defects that are recognized as such by CYRUS.

SPECIFICATIONS

MOVEMENT: self-winding calibre CYR718
BALANCE FREQUENCY: 4Hz (28.800 v/h)
JEWELS: 51
POWER RESERVE: 60 hours
CASE DIAMETER: 42 mm excluding crowns
FRONT AND BACK GLASSES: antireflective sapphire crystal
WATER RESISTANCE: 10 ATM (100 m. – 330 ft.)

KLEPCYS DOUBLE CHRONOGRAPH DICE

EN



CYRUS
GENÈVE

THE CONQUEST OF INNOVATION