

## OWNER'S MANUAL KLEPCYS ALARM

Congratulations on the purchase of your CYRUS timepiece and thank you for the trust!

We are very proud to welcome you to the selected group of happy owners of this exceptional watch.

The Klepcys Alarm is produced in a limited series of 38 pieces for each version : in all steel with blue dial and in steel with black DLC titanium bezel and black dial. This creation boasts an unusual interpretation of the alarm function that incorporates the typical gong of the minute repeater. The Klepcys Alarm is entirely produced in our Manufacture Chronode in Le Locle, Switzerland, and is equipped with the in-house hand-winding CYR1280 calibre which ensures a power reserve of 72 hours.


By choosing CYRUS Klepcys Alarm, you have chosen innovation, exclusivity and a strong identity.

We invite you to consult the instructions for use and wish you an excellent journey in the universe of CYRUS timepieces.

CYRUS, the "Conquest of Innovation" !

## CONTROLS AND INDICATIONS

- A. Hours hand
- B. Minutes hand
- C. Seconds hand
- D. Day (blue) / Night (black) indicator of the main time
- E. 24-hour wakeup alarm
- F. Daytime sector of the alarm
- G. Nighttime sector of the alarm
- H. Hammer of the alarm gong (16 seconds duration)
- I. Small hand positioned to ON or OFF that informs if the alarm is active or not



## OPERATING INSTRUCTIONS

### Crown at 3 o'clock

#### WINDING THE WATCH

Position |

Manual winding. Turn the crown clockwise to wind the watch. When the movement is fully wound (about 45 turns of the crown), a power reserve of 72 hours is granted.

#### SETTING THE ALARM

Position |'

Pull out the crown in position |' to set the time of the alarm (E). Turn the hands, in either directions, to select the chosen hour on the 24-hour scale at 5-minute intervals. The alarm's dial shows two colors : blue for daytime (F) and black for nighttime (G). The alarm gong – through the hammer (H) – strikes for a minimum of 16 seconds.

#### PRESSING THE BUTTON ON THE CROWN

Pressing the button on the crown at 3 o'clock activates or deactivates the alarm function. To know if the alarm is active, just check if the small hand with a luminescent triangular tip at 7 o'clock is positioned to ON or OFF, shown in blue and red (I).

#### SETTING THE MAIN TIME

Position |''

Pull out the crown in position |'' to set the main time and turn the hands clockwise (A = hours hand / B = minutes hand).

Seconds hand (C) requires no adjustment. The indicator (D) informs on the daytime (blue) and nighttime (black).

Caution : To protect the movement against dust and humidity, always push the crown back against the case when you have finished setting the time or alarm.

### Crown at 9 o'clock

This crown is not operational but purely aesthetic.


Finally, we recommend you have your watch controlled and serviced through an official representative of the CYRUS brand every 3 years and you will enjoy your watch for lifetime.

#### SPECIFICATIONS

MOVEMENT: In-house manufactured hand-winding calibre CYR1280  
BALANCE FREQUENCY: 4Hz (28.800 v/h)  
JEWELS: 50  
POWER RESERVE: 72 hours  
CASE DIAMETER: 46 mm excluding crowns  
FRONT AND BACK GLASSES: Antireflective sapphire crystal  
WATER RESISTANCE: 3 ATM (30 m. – 100 ft.)

## KLEPCYS ALARM

EN



CYRUS  
GENÈVE

THE CONQUEST OF INNOVATION